

VTH 25 Parts



Please note the correct order for individual VTH25 parts.

The black collar and the internal ring are both essential to ensure the VTH25 flow sensor continues to operate normally.

